

## V10 固件说明

- 一、请使用神牛固件升级软件 G3 打开该固件进行升级。G3 可在官网下载。
- 二、版本号查看方法：开机后按 “MENU” 按键，进入 C.Fn 菜单。右上角显示 Ver x.x 为版本号。
- 三、版本说明：

版本	更新内容	日期
V1.3	兼徕卡卡引闪器 XProIII 无线系统	2022-08-16
V1.2	1、增加 mode 按键锁住功能（长按 MODE 按键 2 秒） 2、替换字符，RX 替换 Slave。	2020-07-16
V1.1	1、改善热保护系统 2、调整 LED 控制方式。	2019-08-17

注：详细规格请在官网（[www.godox.com.cn](http://www.godox.com.cn)）下载最新说明书。

## V10 Firmware Release Note

- Please update the firmware with Godox firmware update software G3. G3 can be downloaded on the official website.
- How to check the version number: turn on the gear, and press the “MENU” button to enter the C. Fn menu. The top right-hand corner of the screen will show Ver x.x which is the version number.
- Version Instructions:

Version	What's New	Date
V1.3	To add compatibility with Flash Trigger for Leica --- XProIII Wireless System	2022-08-16
V1.2	1. To add the lock function of the mode button (press the MODE button for 2 seconds) 2. To replace the display sign “Slave” with “RX”.	2020-07-16
V1.1	1. To improve heat protection system 2. To adjust the LED control mode	2019-08-17

**Note:** For more details, please download the newest instruction manual on the official website:  
[www.godox.com](http://www.godox.com).