

V10 固件说明

- 一、请使用神牛固件升级软件 G3 打开该固件进行升级。 G3 可在官网上下载。
- 二、版本号查看方法：开机后按 “MENU” 按键，进入 C.Fn 菜单。右上角显示 Ver x.x 为版本号。
- 三、版本说明：

版本	更新内容	日期
V1.2	1、增加 Mode 按键锁住功能（长按 MODE 按键 2 秒）。 2、替换字符，RX 替换 Slave。	2020-07-16
V1.1	1、改善热保护系统。 2、调整 LED 控制方式。	2019-08-17

注：详细规格请在官网（www.godox.com）下载最新说明书。

V10 Firmware Instructions

1. Please update the firmware with Godox firmware update software G3. G3 can be downloaded on the official website.
2. **Firmware Version Checking:** Press the “MENU” button and enter C.Fn menu after turning on the camera flash. The firmware update version (e.g. Version xx will read U-xx) will be displayed on the LCD panel.
3. **Version Instructions:**

Version	Updated Contents	Date
V1.2	1. To add the lock function by pressing the MODE button for 2 seconds. 2. To replace the display sign “Slave” with “RX”.	2020-07-16
V1.1	1. To improve the heat protection system. 2. To adjust the control methods of LED.	2019-08-17

Note: For more details, please download the newest instruction manual on the official website www.godox.com.