

X2T-P 宾得发射器固件说明

- 一、请使用神牛固件升级软件 G3 打开该固件进行升级。G3 可在官网上下载。
- 二、版本号查看方法：发射器开机，按“MENU”按键进入菜单设置，在屏幕右上角显示固件版本号（如 1.1 版本：V1.1）。
- 三、版本说明：

版本	更新内容	日期
V1.1	1、修复设置为 APP 模式下，不发送修改过的值到接收端的问题。 2、恢复出厂设置时，重设蓝牙密码为初始值。	2020-07-20
V1.0	1、初始版本。	2019-08-13

注：详细规格请在官网（www.godox.com）下载最新说明书。

X2T-P Pentax Firmware Instructions

1. Please update the firmware with Godox firmware update software G3. G3 can be downloaded on the official website.
2. **Firmware Version Checking:** Press the “MENU” button and enter C.Fn menu after turning on the camera flash. The firmware update version (e.g. Version 1.1 will read V1.1) will be displayed on the LCD panel.
3. **Version Instructions:**

Version	Updated Contents	Date
V1.1	1. To solve the problem that the modified value wouldn't be sent to the receiver end in APP mode. 2. To reset the Bluetooth password to the initial value when restoring the factory default.	2020-07-20
V1.0	1. The original version.	2019-08-13

Note: For more details, please download the newest instruction manual on the official website www.godox.com.