

V860IIF 固件说明

- 一、请使用神牛固件升级软件 G1 打开该固件进行升级。G1 可在官网上下载。
- 二、版本号查看方法：开机后按住 “Zm/C.Fn” 按键 2 秒，进入 C.Fn 菜单。右上角显示 Ver x.x 为版本号。
- 三、版本说明：

版本	更新内容	日期
V1.2	1、兼容神牛无线宾得（PENTAX）X 系统。	2018-10-23
V1.1	1、新增无线电用户 ID 选项（C.Fn-ID）； 2、新增 SLAVE 模式指示灯开关选项（C.Fn-Sv LED）。	2017-12-01

注：详细规格请在官网（www.godox.com）下载最新说明书。

V860IIF Firmware Instructions

1. Please update the firmware with Godox firmware update software G1. G1 can be downloaded on the official website.
2. **Firmware Version Checking:** Switch the flash on, then press the “Zm/C.Fn” button for 2 seconds and enter C.Fn custom functions. The firmware update version (e.g. Ver X.X) will be displayed on the LCD panel.
3. **Version Instructions:**

Version	Updated Contents	Date
V1.2	1.Compatible with Godox wireless PENTAX system.	2018-10-23
V1.1	1. To add the option of wireless ID (C.Fn-ID); 2. To add the ON/OFF option of SLAVE mode indicator (C.Fn-Sv LED).	2017-12-01

Note: For more details, please download the newest instruction manual on the official website www.godox.com.