

## V1F 固件说明

- 一、请使用神牛固件升级软件 G3 打开该固件进行升级。G3 可在官网上下载。
- 二、版本号查看方法：开机后按 “MENU” 按键，进入 C.Fn 菜单。右上角显示 Ver x.x 为版本号。
- 三、版本说明：

版本	更新内容	日期
V1.2	1、增加 Mode 按键锁住功能（长按 MODE 按键 2 秒）。 2、替换字符，RX 替换 Slave。	2020-07-16
V1.1	1、改善热保护系统。 2、调整 LED 控制方式。 3、解决在机顶模式下曝光补偿（FEC）值翻倍问题。	2019-08-17

注：详细规格请在官网（[www.godox.com](http://www.godox.com)）下载最新说明书。

## V1F Firmware Instructions

1. Please update the firmware with Godox firmware update software G3. G3 can be downloaded on the official website.
2. **Firmware Version Checking:** Press the “MENU” button and enter C.Fn menu after turning on the camera flash. The firmware update version (e.g. Version xx will read U-xx) will be displayed on the LCD panel.
3. **Version Instructions:**

Version	Updated Contents	Date
V1.2	1. To add the lock function by pressing the MODE button for 2 seconds. 2. To replace the display sign “Slave” with “RX”.	2020-07-16
V1.1	1. To improve the heat protection system. 2. To adjust the control methods of LED. 3. To solve the problem that the FEC value will be double when the camera flash is attached on the camera.	2019-08-17

**Note:** For more details, please download the newest instruction manual on the official website [www.godox.com](http://www.godox.com).